



Starter kit accessories DLS/FLS

Item No. 500590



The Starter Kit accessories from Dimetix AG help you to become familiarised with DLS/FLS Distance Laser Sensors. The kit includes all necessary components to operate a DLS/FLS sensor.

Contents

- 1 RS-232 configuration cable (500200) for connecting the DLS/FLS sensor to a PC via an RS-232 serial interface
- 1 Power supply with worldwide usage possible due to wide range input - 100 to 240 VAC - and primary plug system
- 1 CD-ROM with DIMETIX utility software
- 1 DLS/FLS manual

!!! DLS/FLS Laser Distance Sensor must be ordered separately!!!

System requirements

PC system software must support .NET Framework

RS-232 serial interface

In case of only a USB interface on the PC, use the USB/RS-232 converter (500209)

Order information

Item number	Description	Packaging unit
500590	Starter kit accessories DLS/FLS Consisting of: - RS-232 configuration cable (500200) - Power Supply IN: 100 ... 240 VAC, 0.6A Out: 24 VDC, 0.75 A → Not applicable for measuring devices with the heater ! - DLS/FLS Utility Software - DLS/FLS Manual !!! DLS/FLS Laser Distance Sensor must be ordered separately !!!	1 piece

07. Jan. 2014 / Subject to change without notice

500590 Starter kit accessories DLS_FLS_EN_V5.odt